

Thank you for purchasing the Craven Speed TomTom XXL Mounting Kit
Part # CRMC-1000-R51

Contents

Bracket R
2 Plastite Screws
2 Spacers
1 Button Head Bolt
1 Washer
1 TomTom Ball
1 Setscrew
1 Arm

Tools Needed

Philips Head Screwdriver
25 Torx Wrench
3/16 Hex Wrench
3/32 Hex Wrench
Adjustable Wrench

Install the Mounting Bracket

1. Remove factory-mounting screws behind tachometer using the # 25 Torx wrench.
2. Keep these Torx screws safe; you will need to put them back on.
3. Pull the tach towards you to slide the tach off of a hidden rail.
4. Lean the tach towards the wheel to gain access to the 3 screws on the back of it.
5. Using the Philips, remove two of the screws on the back cover of the tach.
6. You may wish to keep the OEM screws, but you will not need them for the install.
7. Drop the 2 spacers into the holes where the screws were.
8. Place the Bracket R so that it fits onto the 2 spacers, it can face so that the mounting point is on either the left or right side of the tach.
9. Affix the bracket with the included Plastite screws.
10. Make sure the bracket is tight and does not wobble.
11. Put the tach back in its original position, and reattach it with the Torx screws.

Assemble the TomTom Mount

1. Locate the 2 screws on the outside of the ring and separate the two pieces.
2. That will allow you to remove the ball from the socket on the mounting ring.
3. Put the ball of the CravenSpeed TomTom adaptor into the socket. Then put the other piece over the ball and TomTom adaptor.
4. Screw the piece of the TomTom adapter back together to complete the ball and socket.
5. Choose either the button head bolt or the thumbscrew to attach the TomTom module to bracket you have already installed.



Questions, Comments, Suggestions

Call Craven Speed at (434)CRA-VEN4