

Thank you for purchasing the Smartphone or GPS Mount

Necessary Tools: 5mm Long hex key, pocket knife

- 1) First carefully remove the vent cover on the dash panel with a pocket knife as shown below. Pull up on the vent fins while gently prying with the knife.



- 2) Remove the bolt revealed after step 1) with your 5mm Long hex key.



- 3) Replace the removed bolt with the ball side of the CravenSpeed ball and socket mount. Use the included rubber washer and aluminum washer and screw in until tight and cover the vent hole with the included, modified vent cover. Tighten the socket side of the mount over the ball using a 5mm hex key.



Questions, Comments, Suggestions?  
Call Craven Speed at 434-272-8364

