



Thank you for purchasing the Craven Speed FlexPod Bracket W

Contents

Bracket W
3 Plastite Screws

Tools Needed

Philips Head Screwdriver
#25 Torx Driver

Please Follow All Directions Carefully.

Attaching the bracket

1. Remove factory-mounting screws behind tachometer using the # 25 Torx wrench.
2. Keep these Torx screws safe; you will need to put them back on.
3. Pull the tach towards you to slide the tach off of a hidden rail.
4. Lean the tach towards the wheel to gain access to the 3 screws on the back of it.
5. Using the Philips, remove the three screws on the back cover of the tach.
6. You may wish to keep the OEM screws, but you will not need them for the install.
7. Place the Bracket W so that it fits into the three holes where the screws were.
8. Affix the bracket with the included Plastite screws.
9. Make sure the bracket is tight and does not wobble.
10. Put the tach back in its original position, and reattach it with the Torx screws.

Please contact CravenSpeed with any questions, comments or suggestions.
(434)CRAVEN4 - (272-8364) support@cravenspeed.com