



Thank you for purchasing the Craven Speed Grille Badge Holder
Italics indicate instruction only applies to '07+ Mini's.

Contents

Front Plate
Back Plate
2 Screws
2 Washers
2 Nuts

Tools Needed

Phillips Head Screwdriver
Flathead Screwdriver
Adjustable Wrench or Pliers

- Open the hood of your MINI.
- *Use the flathead to pop out the four plastic pins above the grille.*
- *Put pins aside for reassembly.*
- *Reach around the side of the grille and squeeze the lower tab.*
- *Pull the grille forward until the tab comes free of its' socket.*
- *Repeat on the opposite side of the grille.*
- *Reach from above to release the lower center tabs.*
- *Pull the grille forward to remove it completely.*
- Slide the two screws through the Front Plate so that they sit flush with the Front Plate.
- Open the hood of your MINI. Place the Front Plate on the raised grille with the screws protruding through to the backside.
- Place the back plate behind the grille so that the screws protrude through the holes in the plate. *It may be necessary to adjust the initial positioning to find a spot where the back plate fits onto the back of the grille.
- Put a washer and nut on one screw and twist it on, repeat with the other screw.
- Hold the nut with the adjustable wrench and use the Phillips head to turn until tight. Repeat with the other screw.
- *Align the grille by matching the lower tabs with their sockets.*
- *Press firmly to lock lower tabs in place.*
- *Pull the pins so the bottom and top end are attached but separated.*
- *Place the lower part of the pins back into in their holes.*
- *Push the tops in to lock them in place.*

No more than two badges should be installed on one grille in order to allow the engine proper respiration.

If you have any trouble with installation please call 888-493-7262, and provide the Craven Speed representative with as much information as possible so that our instructions are up to date and easy to follow.