

Thank you for purchasing the Craven Speed Contour Lever

Contents:

- Handle
- Zip Tie
- 3 Grip Rings
- 1/16 hex wrench
- 3 Setscrews

1. Remove the stock handle

Installation on your vehicle may differ slightly from the supplied instructions.

- ❑ Remove the silver top to the stock handle by prying with a standard screwdriver.
- ❑ Use a standard screwdriver to pop the plastic around the bottom of the brake boot off. You may need one to pinch the center together from each side to release the boot.
- ❑ Use a standard screwdriver to pry up the clip to release the plastic handle from the steel shaft and button. (Pictured at right)
- ❑ Pull the boot over the handle to expose the tie that keeps it in place.
- ❑ Cut the zip tie off and remove the plastic handle entirely. There is no other clip, remove by applying force.

**2. Affix the Contour Lever**

- ❑ Slide the handle into place on the brake lever. We recommend leaving ¼ inch of the release button exposed, you can set it as you prefer.
- ❑ Use the included hex wrench to tighten all three setscrews. It may be easiest to leave them facing up, since they will be covered. (Be sure that they are not hitting gaps on the brake lever mechanism and interrupting lever movement).
- ❑ Use the supplied zip tie to attach the boot to the new handle.
- ❑ Put the boot back into place, and slide the 3 rubber rings into the grooves to hide the setscrews.

If you have any questions or suggestions contact Craven Speed!

Support@CravenSpeed.com Phone:(434)CRAVEN4 (272-8364)