



Thank you for purchasing the Craven Speed Under Tower Indurators  
Part # CRMC-0060

Contents:

- Under Tower Indurators
- These Instructions

Tools Required:

- Torque Wrench
- Metric Socket set

**Jack stands MUST be used with any jack. This installation best performed by 2 people. It is always recommended to have an experienced mechanic on hand at all times. If you doubt your abilities, have an experienced mechanic install this unit.**

1. Jack up the car to rest on jack stands.
2. Remove the 3 nuts from the drivers side strut tower and lower the wheel carefully.
3. Remove the 3 nuts from the passenger side tower and lower that wheel carefully.
4. Take one plate and visually determine its orientation based on the shape of the top of the strut tower.
5. Now bring that plate up through the wheel well and set it, in the proper orientation, on the 3 studs of the strut.
6. Take a second plate and do the same on the passenger side.
7. Once the plates are in place on the top of the struts, you will need to lower the car back onto one strut at a time.
8. Have one person line up the three studs with the holes in the tower while the other very slowly lowers the car into place, then repeat on the other side.
9. Once the car is again resting on the wheels, torque the nuts to 25 FT/LBS.

Questions, Comments, Suggestions  
Call Craven Speed at 888-493-7262