

Thank you for purchasing the Craven Speed Tow Hook

Contents:

- Tow Hook Bolt
- Tow Hook Loop
- 10mm Bolt
- These Instructions

Tools Needed:

- Adjustable Wrench
- Allen Key

Please Follow All Directions Carefully.



- Remove the small round insert in the front lower grill (Gen 1) or the cover plate on the bumper (Gen 2).
- Thread the Tow Hook Bolt into the mount hole.
- Set the Tow Hook Loop to the up position and tighten 10mm Bolt.

To Stow: Loosen the 10mm bolt, set the Tow Hook Loop to the down position and firmly re-tighten the 10mm bolt.

Towing should be done at no faster speeds than 5mph, and always by a professional. Do not tow at excessive angle or incline. Tow at your own risk.

Question, comments, suggestions; call 434-CRAVEN4 (503.272.8364)
Please provide the Craven Speed representative with as much information as possible so that our instructions are up to date and easy to follow.