



Thank you for purchasing the FlexPod Fixie Garmin Mounting Kit

CRMC-1000-FX140

Contents:

- Fixie Mount
- 2 Plastite Screws
- 2 Plastic Spacers

Required:

- iPhone 3G/3GS
- Torx T-20, T-25, T-27
- 4mm or 5/32 Hex Wrench
- #2 Philips Screwdriver

- 1) Remove factory-mounting screws from behind tachometer. Press the release button on the green wiring attachment to detach it and lift the unit off of the steering wheel. Keep the factory screws!
- 2) Remove two of the factory screws from the back of the tachometer. Which two holes to use depends on which side you want the iPhone on. Use the top hole along with either the right or left if you want the iPhone on the right or left. Install the spacers, and bolt the Fixie to the back of the tachometer body with the long screws.
- 3) Reinstall your tachometer. The phone should clip easily into the cradle.

Questions, Comments, Suggestions?
Call Craven Speed at (434)CRAVEN4 (272-8364)
support@cravenspeed.com