

Thank you for purchasing the FlexPod Fixie Garmin Mounting Kit

CRMC-1000-FX51

Contents:

- Bracket R
- 2 Plastite Screws
- 2 Plastic Spacers

Required:

- Garmin GPS with Car Mount
- Torx T-20, T-25, T-27
- 4mm or 5/32 Hex Wrench
- #2 Philips Screwdriver

- 1) Remove factory-mounting screws from behind tachometer. Press the release button on the green wiring attachment to detach it and lift the unit off of the steering wheel. Keep the factory screws!
- 2) Remove two of the factory screws from the back of the tachometer. Which two holes to use depends on which side you want the GPS on. Use the top hole along with either the right or left if you want the GPS on the right or left. (see pic) Install the spacers, and bolt the Fixie to the back of the tachometer body with the long screws.
- 3) Reinstall your tachometer. The ball at the outer end is sized to fit the standard clip provided with Garmin portable GPS units. Pull the mounting clip off the stock Garmin GPS suction cup mount. Gently but firmly press the socket onto the ball at the end of the extension arm. The clip should pop right onto the ball.
- 4) Finally, place your GPS unit into the clip and plug it in.





Questions, Comments, Suggestions?
Call Craven Speed at (434)CRAVEN4 (272-8364)
support@cravenspeed.com