



Thank you for purchasing the Craven Speed Device Cradle (Gen 1)

Contents		Tools Needed
1 Bracket Z	1 Button Head Bolt	Philips Head Screwdriver
2 Plastite Screws	3 Washers	# 27 Torx Wrench
2 Spacers	1 Swivel Cradle Module	5/32 Hex Wrench

Please Follow All Directions Carefully.

### **Install the Mounting Bracket**

1. Remove factory-mounting screws behind tachometer using the # 27 Torx wrench.
2. Keep these Torx screws safe; you will need to put them back on.
3. Pull the tach towards you to slide the tach off of a hidden rail.
4. Lean the tach towards the wheel to gain access to the 2 screws on the back of it.
5. Using the Philips Screwdriver, remove the three screws on the back cover of the tach.
6. You may wish to keep the OEM screws, but you will not need them for the install.
7. The spacers go into the now empty screw holes.
8. Place the Bracket Z so that it fits onto the spacers. It can face so that the mounting point is on either the left or right side of the tach, up or down.
9. Affix the bracket with the included Plastite screws and the silver washers.
10. Make sure the bracket is tight and does not wobble.
11. Put the tach back in its original position, and attach it with the Torx screws.



### **Add Module**

12. Use the Button Head Bolt and plastic washer to attach the arm to the mounting bracket with a 5/32" hex wrench. Adjust to desired position then tighten down.
13. Snap in your mobile device and away you go! You will now be able to swivel the device for Horizontal or Vertical viewing quickly and easily!

**Contact Craven Speed at (434)CRA-VEN4 or [support@cravenspeed.com](mailto:support@cravenspeed.com) with any questions, comments or suggestions.**