



Thank you for purchasing the Bluetooth OBDII Connector  
SKU#CRU-2100

Contents:  
ELM327 OBD2 BT Transceiver

Required:  
Droid, PC, Mac or other BT  
enabled device

Recommended:  
Torque Application for Android  
(Ad-supported or US\$5 version)



FlexPod Smartphone Mounting bracket

All OBDII Bluetooth transceivers have been tested for quality at our facility before shipment; each unit is paired and data transmission verified. If, for any reason, you are not 100% satisfied with this product, return it for a full refund.

Installation Instructions:

- 1) Connect OBDII Bluetooth Transceiver to the OBD socket in your vehicle and turn ignition to position 2, or until the red LED indicator is illuminated.
- 2) Pair the ELM327 with your device. In Android, these setting can be found by pressing Settings->Wireless & networks->Bluetooth settings->Scan for devices.
- 3) Select the OBDII (ELM327) device. When prompted, enter the pairing code. The pairing code is 1234. The correct status will read: "Paired but not connected"
- 4) Open your OBD Scanning software and make sure that you have selected the OBDII (ELM327) device as the reporting device.
- 5) If you are using Torque BHP, verify that everything is working properly when all icons on the top right of the screen are blue and have stopped blinking. Have fun viewing/logging data!!

**Questions, Comments or Suggestions?**  
**Call Craven Speed at (434)CRAVEN4 (272-8364)**  
**Email: [support@cravenspeed.com](mailto:support@cravenspeed.com)**