



Thank you for purchasing the Craven Speed Swivel Device Cradle (Gen 2)

### Contents

Bracket R  
2 Plastite Screws  
2 Spacers  
1 Button Head Bolt  
1 Washer  
1 Swivel Cradle Module  
1 Thumb screw

### Tools Needed

Philips Head Screwdriver  
# 27 Torx Wrench  
5/32 Hex Wrench

Please Follow All Directions Carefully.

### Install the Mounting Bracket

1. Remove factory-mounting screws behind tachometer using the # 25 Torx wrench.
2. Keep these Torx screws safe; you will need to put them back on.
3. Pull the tach towards you to slide the tach off of a hidden rail.
4. Lean the tach towards the wheel to gain access to the 2 screws on the back of it.
5. Using the Philips, remove the three screws on the back cover of the tach.
6. You may wish to keep the OEM screws, but you will not need them for the install.
7. Drop the 2 spacers into the holes where the screws were.
8. Place the Bracket R so that it fits onto the 2 spacers, it can face so that the mounting point is on either the left or right side of the tach.
9. Affix the bracket with the included Plastite screws.
10. Make sure the bracket is tight and does not wobble.
11. Put the tach back in its original position, and reattach it with the Torx screws.



### Add Swivel Cradle Module

12. Use the Button Head Bolt and washer to attach the arm to the installed mounting bracket with a 5/32" hex wrench. Adjust to desired position then tighten down.
13. Snap in your mobile device and away you go! You will now be able to swivel the device for Horizontal or Vertical viewing quickly and easily!

**Contact Craven Speed (434-272-8364) with any questions, comments or suggestions.**